

After soldering hummingbird and flower attach the hummingbird to the flower with the beak wire.
Be sure all the edges are finished before attaching to the 6" circle bevel

