

	0119972247			
020	A 0099974547 Замена: 0099978547	SEAL RING	-	
020	A 0099978547 Замена: 0059979047 0119972247	SEAL RING, Crankschaft sealing,front	001	
020	A 0119972247 Замена: 0059979047 0099978547	SEAL RING, Crankschaft sealing,front	001	
023	N900037008100 Замена: 000007008244	DOWEL PIN	-	
023	N000007008244	CYLINDRICAL PIN	002	
026	A 6170310107	COUNTERWEIGHT	001	005
029	N000007003201	CYLINDRICAL PIN, In counterweight	001	027
044	A 6150301205	FLYWHEEL	001	
047	A 1800320605	RING GEAR	001	
050	A 1150320006	FOLLOWER	001	
053	A 1150320076	WASHER	001	
059	A 1089900319 Замена: 1109900419	SCREW	-	
059	A 1109900419	SCREW	012	
065	A 0009976941 Замена: 0019971241	SEAL RING	-	
065	A 0019971241	SEAL RING	001	
080	A 6170320015	POINTER	001	005 016 018
086	N000961018019	SCREW	001	008
089	A 1279930026	DISC SPRING	003	000
095	A 6170350212	PULLEY	001	016
095	A 6170350112	PULLEY	001	016
095	A 6170351112	PULLEY	001	017
101	A 6170300103	VIBRATION ABSORBER	001	
113	N000912008026 Замена: 000912008072	SCREW	-	
113	N000012008072	SCREW	-	

