



VV's Victorian Prints

3719 S. 194th Street ♦ SeaTac, WA 98188 ♦ (206) 588-2835 ♦ www.vvprints.com

100% Washable Cotton Fabric Sheets

6-Sheet Pack

Can be used in all Inkjet Printers



Use your computer and inkjet printer (or stand-alone inkjet copier) to print our images, your favorite photographs or designs on our specially treated fabric sheets. Just print, wait for the ink to dry, remove the paper backing, rinse in cool water, let dry (okay to carefully dab with a towel).

After completing the above you will have a machine washable piece of fabric and will be ready to create your own unique crafts, clothing or home furnishings!

These cotton poplin fabric sheets are perfect for use in



Quilts • Pillows

Scrapbooks

Flags and Banners

Costumes • Clothing

Aprons, Towels,



Potholders, and so much more!

Hints for jam-free printing *(Please read the directions below & the questions on the back before printing.)*

- The fabric and the backing paper must be tight and flat together. If the paper and fabric become separated, use a hot iron on the paper side to reseat the paper and fabric together.
- Before you load any fabric sheets into your printer be sure to cut or clip loose threads. Do not pull threads.
- Do not force a fabric sheet into any printer. Place the sheet flush against the paper guide and square with the entry roller.
- Feed single sheets at a time. *(If you are using an HP printer, the print side goes down and the 'paper' side up in the feed tray.)* If you are not sure how your printer feeds, mark a blank piece of regular paper and see how it goes through.
- Humidity and storage conditions of the fabric sheets will affect performance. Store flat in low humidity conditions. Other conditions affecting performance are the age of your printer and the condition of the pickup and drive rollers inside the printer.
- Check the printer utility for 'cleaning' instructions if the output quality appears to have changed OR if you can see banding or white lines through the image. Use the plain or plain/thick paper setting in the paper feed/select screen.
- Fabrics and papers will leave dust and lint in your printer. Using a can of compressed air to 'blow' debris out of the printer mechanisms is good preventative maintenance and will help to keep your printer clean.