

CLICK ON TEXT OR ENLARGER ICON BELOW FOR LARGER / BETTER VIEW

SEW ON PRINTABLE INKJET FABRIC SHEETS Instructions

NOTE: This fabric is for **INKJET PRINTERS ONLY**. Do not use laser printers or color copying machines. Fabric can be washed and dry cleaned. The quality and colorfastness of your fabric printout will depend on several factors including the type of printer, printer ink used, total exposure to light, number of washings and chemicals in your water.

- 1. Prepare your image for printing on your computer:** Scan in a photo or other image, use a digital photo or create a design using design software.
- 2. Prepare fabric for printing:** Flatten any curl that may be in the fabric by weighting the fabric sheet down overnight with books. **Trim any loose threads from the fabric. Do not pull them.**
- 3. Prepare printer:** Adjust printer settings to Plain Paper (use **Thick Paper** setting if printer has this option) and **Best Quality**. Different printers require different settings, so test your printout on paper before printing on fabric.
- 4. Remove all paper from tray.** (Use **Manual Feed** if available.) Insert fabric one sheet at a time. **Print onto fabric side of sheet.**
- 5. Let dry 15 minutes** after printing. (For Viverra inks, let printout dry for several days.)
- 6. Peel off plastic backing.**
- 7. To take off any excess ink, soak in room temperature water for 10 minutes.** Then rinse until water runs clear. Lay flat to dry.
- 8. Hand stitch or machine sew onto your project.**

CARE INSTRUCTIONS

- Wash gently by hand or machine, using mild detergent. **Do not use bleach.** Lay flat to dry.
- Iron on Low to Medium heat, if desired.
- **Do not place in direct sunlight.** The colorfastness of your image depends on how colorfast your printer ink is. **All fabric will fade in direct sunlight.**
- Store unused fabric flat, in its original packaging.
- **Keep out of humid conditions.**

TIPS

- Since printers do not print white, the white in your image will be the same as the fabric sheet.
- You can snip off the corners of the leading edge of the fabric or fold masking tape along the leading edge to help it feed through the printer.