

































# Fabric Care Symbols Guide

Machine Wash	Bleach	Tumble Dry	Dry	Iron	Dry Clean
<b>TEMPERATURE</b>		<b>HEAT SETTING</b>		<b>TEMPERATURE</b>	
 Cool/Cold  Warm  Hot	 Dry Bleach (when needed)  Only Non-chlorine Bleach (when needed)  Do Not Bleach	 No Heat  Low  Medium  High  Any Heat	 Line Dry/ Hang to Dry  Drip Dry  Dry Flat	(Dry or Steam)  Low  Medium  High	 Dry Clean  Do Not Dry Clean
<b>CYCLE</b>					
 Normal  Permanent Press  Delicate/Gentle		<b>CYCLE</b>	 Dry in The Shade	<b>OTHER</b>	 No Steam
<b>OTHER</b>					
 Do Not Wash  Hand Wash		 Permanent Press  Delicate/Gentle	 Do Not Dry  Do Not Wring	 Do Not Iron	
<b>OTHER</b>		<b>OTHER</b>			
 Do Not Tumble Dry					