



X-Arcade

Nintendo Wii U Adapter

NOTE: Supports Classic Controller Games and Virtual Console Games Only

- 1) Plug the Console Cable (Included with your original X-Arcade) into the Serial Port on the X-Arcade™.
- 2) Plug the other end of the Console Cable into Serial Port on the PS2 X-adapter.
- 3) Connect other end of PS2 adapter into the PS2-Wii Adapter (Only the 'P1' side is used for Solo)
- 4) **First power on your Wii console and turn on your Wii controllers**, then connect the other end of PS2-Wii adapter into the bottom of your Wii controller.

If you have problems, unplug the Wii adapters from the controller and wait 15 seconds before plugging them back in.



- + Y = D-PAD (default)
- + X = Analog 1 (Left Analog Thumbstick)
- + Zr = Analog 2 (Right Analog Thumbstick)
- + Zl = Slow Sensitivity for Analog 1
- + L = Normal Sensitivity for Analog 1
- + + = Home